



FOX EOS 10000

No	Parts Name
1	FRONT CLUTCH KNOB
2	SPOOL
3	SPOOL WASHER
4	CLICKER PLATE
5	CLICKER WASHER
6	ROTOR NUT
7	ROTOR INSERT
8	ROTOR NUT RETAINER SCREW
9	BAIL ARM WIRE
10	LEFT SIDE PIVOT PIN
11	LEFT SIDE BAIL ARM HOLDER
12	BAIL ARM PLATE
13	PIVOT SCREW
14	PIVOT SCREW COVER LEFT
15	ROLLER WHEEL SCREW
16	ROLLER WHEEL PIVOT ARM
17	BAIL ARM HOLDER

18	ROLLER WHEEL WASHER 1
19	ROLLER WHEEL
20	ROLLER WHEEL BEARING
21	ROLLER WHEEL WASHER 2
22	PIVOT ARM BUSH
23	PIVOT SCREW
24	PIVOT SCREW COVER RIGHT
25	ROTOR SIDE COVER SCREW
26	ROTOR SIDE COVER
27	RETURN ARM
28	RETURN SPRING ACTUATOR
29	RETURN SPRING
30	RETURN SPRING ARM
31	EOS 10000 ROTOR
32	OSCILLATING SHAFT
33	ROTOR WASHER
34	BEARING PLATE
35	BEARING PLATE SCREWS

36	PINION BEARING
37	BEARING SPACER
38	BEARING RETURN SPRING
39	ONE-WAY BEARING
40	WORM RETAINER SCREW
41	WORM RETAINER PLATE 1
42	WORM RETAINER PLATE 2
43	WORM BEARING SPACER
44	WORM BEARING SPACER
45	WORM BEARING
46	WORM SHAFT DRIVE GEAR
47	WORM SHAFT
48	WORM BEARING
49	WORM RETAINER PLATE 2
50	ANTI REVERSE LINKAGE
51	LINKAGE SPRING
52	ANTI REVERSE SWITCH
53	SWITCH RETAINING SCREW

54	SUPPORT SHAFT RETAINING PLATE
55	RETAINING PLATE SCREW
56	OSCILLATION SUPPORT SHAFT
57	OSCILLATION BLOCK
58	OSCILLATION TOOTH BUSH
59	OSCILLATION TOOTH
60	TOOTH RETAINING PLATE
61	RETAINING PLATE SCREW
62	LOWER BODY COVER PLATE
63	LOWER BODY COVER PLATE SCREW
64	HANDLE CAP
65	HANDLE CAP WASHER
66	SIDE COVER - COVER PLATE
67	SIDE COVER SCREW CAPS
68	SIDE COVER
69	FREESPOOL CLICKER SPRING
70	CLICKER SPRING RETAINER
71	HANDLE SHAFT BEARING 1

72	FACE GEAR WASHER
73	FACE GEAR
74	HANDLE SHAFT BEARING 1
75	RETAINING PLATE SCREW
76	FREESPOOL LOCK RETAINING PLATE
77	FREESPOOL LOCK
78	FREESPOOL LOCK SPRING
79	EOS 10000 BODY
80	BODY COVER PLATE
81	EOS 10000 HANDLE
82	FREESPOOL LEVER SCREW 1
83	FREESPOOL LEVER SCREW 2
84	RIGHT SIDE FREESPOOL LEVER
85	FREESPOOL LEVER WASHER
86	FREESPOOL ACTUATOR SPRING 1
87	FREESPOOL ACTUATOR 1
88	FREESPOOL ACTUATOR BEARING
89	FREESPOOL ACTUATOR 2

90	FREESPOOL ACTUATOR SPRING 2
91	ACTUATOR ENGAGEMENT PLATE
92	ENGAGEMENT PLATE SCREW
93	LEFT SIDE FREESPOOL LEVER
94	FREESPOOL LOCK RETAINING PLATE
95	FREESPOOL BODY
96	FREESPOOL DRAG WASHER 1
97	FREESPOOL BODY WASHER
98	FREESPOOL DRAG WASHER 3
99	FREESPOOL ORIENTATION WASHER
100	FREESPOOL DRAG SPRING
101	FREESPOOL ADJUSTER BODY
102	FREESPOOL KNOB RETAINER
103	DRAG KNOB WASHER
104	DRAG KNOB INDEX PIN
105	DRAG KNOB INDEX SPRING
106	FREESPOOL DRAG KNOB