


ULTRON RAGE 1500 PRO



| NO. | PARTS NAMES |
|-----|----------------------------|
| 1 | BODY |
| 2 | BODY COVER |
| 3 | SCREW |
| 4 | SCREW |
| 5 | BODY DECORATION COVER |
| 6 | SCREW |
| 7 | BALL BEARING |
| 8 | OSCILLATION GEAR |
| 9 | SCREW |
| 10 | SLIDE |
| 11 | SCREW |
| 12 | SLIDE GUIDE PIN |
| 13 | BALL BEARING |
| 14 | DRIVE GEAR |
| 15 | WASHER |
| 16 | BALL BEARING |
| 17 | BODY SIDE |
| 18 | SCREW |
| 19 | BODY SIDE DECORATION COVER |
| 20 | SCREW |
| 21 | MAIN SHAFT |
| 22 | PINION GEAR |
| 23 | BALL BEARING |

| | |
|----|-----------------------------|
| 24 | ONE WAY CLUTCH |
| 25 | BEARING PLATE |
| 26 | BEARING |
| 27 | ONE WAY CLUTCH FIXING PLATE |
| 28 | SCREW |
| 29 | WASHER |
| 30 | ANTI-REVERSE BUTTON |
| 31 | SCREW |
| 32 | ANTI-REVERSE LINKAGE |
| 33 | SPRING |
| 34 | SPRING |
| 35 | SCREW |
| 36 | BAIL HOLDER COVER |
| 37 | SCREW |
| 38 | BAIL HOLDER |
| 39 | BUSH |
| 40 | ROTOR |
| 41 | BAIL ASS'Y |
| 42 | BAIL SLIDE |
| 43 | LINE ROLLER |
| 44 | BALL BEARING |
| 45 | WASHER |
| 46 | BAIL ARM |
| 47 | SCREW |

| | |
|----|----------------------|
| 48 | BUSH |
| 49 | BAIL ARM SUPPORT PIN |
| 50 | SPRING |
| 51 | SCREW |
| 52 | KICK LEVER |
| 53 | BAIL ARM COVER |
| 54 | SCREW |
| 55 | WASHER |
| 56 | ROTOR NUT |
| 57 | SPOOL ASS'Y |
| 58 | LINE WASHER |
| 59 | DRAG WASHER |
| 60 | LINE WASHER |
| 61 | DRAG WASHER |
| 62 | LINE WASHER |
| 63 | DRAG WASHER |
| 64 | SPRING |
| 65 | DRAG KNOB |
| 66 | CLICK GEAR |
| 67 | WASHER |
| 68 | HANDLE ASS'Y |
| 69 | WASHER |
| 70 | HANDLE CAP |